

POP-UP CANOPY INSTRUCTIONS



Set up

1. Remove cover bag by lifting up and off the canopy frame. Please place it where it can be replaced after the canopy is dismantled.



2. Gently pull legs apart to expand frame. Two people working on opposite sides make the job easier.
3. Expand canopy fully by raising the sliders at the corners to the top of the legs. Note: Pins in sliders will “click” and lock when raised to proper level.



4. Adjust canopy height by raising legs to desired level. Note: Pins in legs will “click” and lock automatically.

Dismantle

1. Pull pins on legs to lower to the ground.
2. Pull pins on all sliders to release truss system.
3. Push legs together to compress frame back to original size. Lift legs to avoid bending.

Warning: This free-standing canopy can be lifted off the ground in some weather conditions. If severe weather or high winds arise, dismantle the canopy immediately to avoid possible damage and/or possible injury.