

# PROPANE OVEN

(without top burners)



609-689-9500

**NOTE:** While lighting a manual pilot system, sufficient time must be allowed for the proper pilot flame to heat the thermocouple that will hold the safety valve open. If lighting for the first time, allow some time for air to be purged from the gas distribution system.

## TO LIGHT THE OVEN PILOT:

1. Attach propane tank.
2. When ready to use oven, turn propane **ON**.
3. Make sure all oven controls are set to **OFF**.
4. Open oven door and remove the oven shelf on bottom to expose pilot light.
5. Turn main oven control (red dial) to **ON** position.
5. Depress and hold down the red safety button on the outside below the oven door, while lighting the pilot on the inside. Hold the red safety button down for at least 45 seconds.
6. Release the red safety button. The pilot should stay lit. If not, repeat the process.
7. Replace oven shelf on bottom of oven.
8. Set the thermostat to the desired temperature. The main burners inside the oven will light.

**NOTE:** Pilots cannot be shut off unless the main gas supply to the appliance is shut off.

## TO TURN OFF THE OVEN PILOT:

1. Turn the thermostat to the **OFF** position.
2. Turn the main oven control (red dial) to **OFF** position.
3. Close the propane tank.
4. Disconnect propane tank.



FOR YOUR SAFETY



Keep area around appliance clear of combustibles.

**WARNING:** Exterior surfaces may become hot enough to cause serious burns.

**DO NOT TOUCH** without proper protection.

If you smell gas near any part of the system, turn off propane tank and leave area immediately.

**DO NOT** use or store propane indoors or under tents.

**ALWAYS** have a fire extinguisher readily available.